




- de** Montageanleitung
- en** Mounting instructions
- fr** Instructions de montage
- sv** Monteringsinstruktion
- nl** Montage-handleiding
- it** Istruzioni di montaggio
- fi** Asennusohje
- es** Instrucciones de montaje
- da** Monteringsvejledning

- Durchgangsventile PN25
- Two-port seat valves PN25
- Vannes 2 voies PN25
- 2-vägsventiler PN25
- Doorstroomafsluiters PN25
- Valvole a due vie PN25
- Kaksitieventtiilit PN25
- Válvulas de 2 vías PN25
- Vovejsventiler PN25

VVG549...




VVG549...




A → AB A = 0 ... 100%
AB = 0 ... 100%


VVG549...K




A → AB A = 0 ... 100%
AB = 0 ... 100%

VVG549... + SQS359...






DN [mm]	D	Valve type	H [mm]	H1 [mm]	H2 [mm]	L1 [mm]	L2 [mm]	L3 [mm]	L4 [mm]	L5 [mm]	N [mm]	B [mm]	G [kg]
15	G $\frac{3}{4}$ B	VVG549.15-0.25 ... 2.5	212	58	97	65	32,5	31.5	111	137	33	11,5	0.48
20	G1B	VVG549.20-4K	230	78	120	70	35	37.5	117	153	37	12	0.63
25	G1 $\frac{1}{4}$ B	VVG549.25-6.3K	230	78	120	75	37,5	37.5	123	158	42	12	0.72



ALS15, ALS20, ALS25



ALG12, ALG15, ALG20

DN [mm]	D	Valve type	Fitting type	$\varnothing P$ [mm]	N1 [mm]	G [kg]	Fitting type	$\varnothing E$ [mm]	N" [mm]	G [kg]
15	G $\frac{1}{2}$ B	VVG549.15-0.25 ... 0.63	ALS15	21.3	32	0.08	ALG12	Rp $\frac{3}{8}$	32	0.08
20	G1B	VVG549.20-4K	ALS20	26.8	41	0.10	ALG15	Rp $\frac{1}{2}$	41	0.10
25	G1 $\frac{1}{4}$ B	VVG549.25-6.3K	ALS25	33.7	50	0.16	ALG20	Rp $\frac{3}{4}$	50	0.16