





de Montageanleitung
en Mounting instructions
fr Instructions de montage
sv Monteringsinstruktion
nl Montage-aanwijzing
it Istruzioni di montaggio
fi Asennusohje
es Instrucciones de montaje
da Monteringsvejledning

Kabeltemperaturfühler
Cable temperature sensor
Sonde de température à câble
Kabeltemperaturgivare
Temperaturopnemer met Kabel
Sonda di temperatura a cavo
Uppoanturi
Sonda de temperatura para placa
Kabeltemperaturføler

QAZ21.682/101
QAZ21.685/101



max. erlaubter Montagebereich am Sauggasrohr (nicht unterhalb)
 max. permissible mounting location at the suction gas pipe (not below)
 Zone autorisée pour montage sur tube de gaz aspiré (pas dessous)
 tillåtet placeringsområde vid montering på suggasröret (inte under)
 Max. toelaatbaar montagegebied aan de zuiggasleiding (niet lager)
 max. inclinazione della sonda rispetto all'interasse del tubo (vedi schema).
 maks. sallittu asennusalue imukaasuputken päällä (ei alapuolella)
 temperatura máxima aceptable de montaje en el tubo de aspiración de gas (nunca por debajo).
 max. tilladt monteringsområde på sugegasrøret (ikke under)



Maße in mm
 Dimensions in mm
 Dimensions en mm
 Mått i mm
 Maten in mm
 Dimensioni in mm
 Mítat mm
 Dimensiones en mm
 Mål i mm